

CIK REAR PROTECTION SYSTEM HOOK INSTALLATION

Electric KartLift or WinchLift

Simply remove the old hooks and reinstall the CIK/RPS hook in the same manner, using the holes nearest the end of the bar. It may be necessary to drill new holes or to use the outer set of holes on the KartLift to match up to your specific bumper.



Pro KartLift

1. Remove the existing hooks.
2. Mark out the location of the new hooks using drawings as guide.
3. Drill 4 new 5/16" holes through the KL handle.
4. Install hooks as in drawings and photos.

Center holes on tube

